

## Elephant Bike Set Up Instructions

Your Elephant Bike has been delivered– welcome to the herd! If you're not familiar with setting up a delivered bike, these instructions will be a handy guide as to how to attach the pedals and carrier and how to align your handle bars. But we're more than happy to provide help and support over the phone if you prefer to speak to a human, just give us a call (Mon-Fri 9am-5pm) and we'll do our absolute best to help– Telephone 01543 888494



**No 1: Your Tool Kit**  
1 x Multi Tool  
1 x 5mm allen key



**No 2:** Handlebars with allen key fitting

### **Pictures No 2 and 3: Aligning your handlebars and adjusting their height**

There are two types of Elephant Bike handle bars. You will either have an allen key fitting (pic 2) or a standard nut fitting (pic 3),

Depending on the type of fitting you have loosen the bolt using either a 13mm spanner or 6mm allen key.

**IMPORTANT: ONLY UNSCREW THE FITTING BY A COUPLE OF TURNS, JUST ENOUGH TO MAKE THE HANDLEBARS LOOSE, OTHERWISE IT IS POSSIBLE FOR THE CONE TO DROP WITHIN THE FRAME, IF THIS HAPPENS ACCIDENTALLY, PLEASE PHONE US.**

Stand at the front of your bike with the front wheel between your legs. Gentle rotate (it may need a wiggle) the handle bars into position. Then tighten the bolt securely again.



**No 3:** Handlebars with nut fitting



**No 4:** Pedals  
(with left and right highlighted in red)

### **Picture No 4 : Attaching the pedals**

Please note there is a left hand pedal and a right hand pedal (see picture 5).

You will see L or R on the end of the thread to save confusion.

Start attaching the pedals by hand. The left pedal turns clockwise. The right pedal turns anti-clockwise. Finish tightening both pedals with the 15mm spanner.



**No 5:** Quick Release Adjustor

### **Pictures No 5 and 6: Adjusting height of the seat**

Your bike will either be fitted with a quick release bolt or a standard nut and bolt.

In the case of a quick release bolt just pull the lever away from the frame to loosen it. Use the saddle to then move the seat post up or down as required. Be careful not to exceed the minimum mark (line) . Push the lever towards the bike to tighten.

In the case of a standard bolt , use a 13mm spanner to loosen the nut. Use the saddle to then move the seat post up or down as required. Be careful not to exceed the minimum mark (line). Use a 13mm spanner to tighten the nut.



**No 6:** Adjusting the saddle height